

Ref	Tinteiros P/ impressoras Epson	Cap.(ml)
PK-T001	Tinteiro p/ Epson Stylus Photo 1200	53
PK-T003	Tinteiro p/ Epson Stylus Color 900 / 900N / 900G / 980 Preto	34
PK-T005	Tinteiro p/ Epson Stylus Color 900 / 900N / 900G / 980 Cor	51
PK-T007	Tinteiro p/ Epson Stylus Photo 790/870/890/875DC/895/900/915/1270/1290/1290S Preto	17
PK-T008	Tinteiro p/ Epson Stylus Photo 790/870/890/875DC/895/915 Cor	42
PK-T009	Tinteiro p/ Epson Stylus Photo 900/1270/1290/1290S Cor	53
PK-T013	Tinteiro p/ Epson Stylus Color 480/480SXU/580/C20/C20SX/C40/C40+ Preto	15
PK-T014	Tinteiro p/ Epson Stylus Color 480/480SXU/580/C20/C20SX/C40/C40+ Cor	34
PK-T017	Tinteiro p/ Epson Stylus Color 680/680T/685 Preto	18
PK-T018	Tinteiro p/ Epson Stylus Color 680/680T/685 Cor	39
PK-T019	Tinteiro p/ Epson Stylus Color 880/880T Preto	23
PK-T020	Tinteiro p/ Epson Stylus Color 880/880T Cor	34
PK-T026	Tinteiro p/ Epson Stylus Photo 810/820/830/830U/C50/925/935 Preto	17
PK-T027	Tinteiro p/ Epson Stylus Photo 810/820/830/830U/C50/925/935 Cor	42
PK-T028	Tinteiro p/ Epson Stylus C60 Preto	18
PK-T029	Tinteiro p/ Epson Stylus C60 cor	39
PK-T036	Tinteiro p/ Epson Stylus C42SX/C42UX/C44/C46 Preto	10
PK-T037	Tinteiro p/ Epson Stylus C42SX/C42UX/C44/C46 Cor	23
PK-T040	Tinteiro p/ Epson Stylus C62/CX3200 Preto	18
PK-T041	Tinteiro p/ Epson Stylus C62/CX3200 Cor	39
PK-T0321	Tinteiro p/ Epson Stylus C70/C70+/C80/C82/CX5200/CX5400 Preto	33
PK-T0322	Tinteiro p/ Epson Stylus C70/C70+/C80/C82/CX5200/CX5400 Azul	15
PK-T0323	Tinteiro p/ Epson Stylus C70/C70+/C80/C82/CX5200/CX5400 Magenta	15
PK-T0324	Tinteiro p/ Epson Stylus C70/C70+/C80/C82/CX5200/CX5400 Amarelo	15
PK-T0422	Tinteiro p/ Epson Stylus C82/CX5200/CX5400 Azul	15
PK-T0423	Tinteiro p/ Epson Stylus C82/CX5200/CX5400 Magenta	15
PK-T0424	Tinteiro p/ Epson Stylus C82/CX5200/CX5400 Amarelo	15
PK-T0331	Tinteiro p/ Epson Stylus Pro 950 Preto	15

PK-T0332	Tinteiro p/ Epson Stylus Pro 950 Azul Claro	15
PK-T0333	Tinteiro p/ Epson Stylus Pro 950 Magenta	15
PK-T0334	Tinteiro p/ Epson Stylus Pro 950 Amarelo	15
PK-T0335	Tinteiro p/ Epson Stylus Pro 950 Azul Claro	15
PK-T0336	Tinteiro p/ Epson Stylus Pro 950 Magenta Claro	15
PK-T0341	Tinteiro p/ Epson Stylus Photo 2100 Preto	15
PK-T0342	Tinteiro p/ Epson Stylus Photo 2100 Azul	15
PK-T0343	Tinteiro p/ Epson Stylus Photo 2100 Magenta	15
PK-T0344	Tinteiro p/ Epson Stylus Photo 2100 Amarelo	15
PK-T0345	Tinteiro p/ Epson Stylus Photo 2100 Azul Claro	15
PK-T0346	Tinteiro p/ Epson Stylus Photo 2100 Magenta Claro	15
PK-T0347	Tinteiro p/ Epson Stylus Photo 2100 Cinzento	15
PK-T0348	Tinteiro p/ Epson Stylus Photo 2100 Preto Mate	15
PK-T0431	Tinteiro p/ Epson C84/C86/CX6400/CX6600 Alta Capacidade Preto Pigmentado	33
PK-T0441	Tinteiro p/ Epson SC64/C66/C84/C86/CX3600/CX3650/ CX6400/CX6600 Preto	15
PK-T0442	Tinteiro p/ Epson SC64/C66/C84/C86/CX3600/CX3650/ CX6400/CX6600 Azul	11
PK-T0443	Tinteiro p/ Epson SC64/C66/C84/C86/CX3600/CX3650/ CX6400/CX6600 Magenta	11
PK-T0444	Tinteiro p/ Epson SC64/C66/C84/C86/CX3600/CX3650/ CX6400/CX6600 Amarelo	11
PK-T0481	Tinteiro p/ Epson Stylus Photo R200/R220/R300/R340/R320/R500/RX500/RX600/RX620/RX640 Preto	15
PK-T0482	Tinteiro p/ Epson Stylus Photo R200/R220/R300/R340/R320/R500/RX500/RX600/RX620/RX640 Azul	15
PK-T0483	Tinteiro p/ Epson Stylus Photo R200/R220/R300/R340/R320/R500/RX500/RX600/RX620/RX640 Magenta	15
PK-T0484	Tinteiro p/ Epson Stylus Photo R200/R220/R300/R340/R320/R500/RX500/RX600/RX620/RX640 Amarelo	15
PK-T0485	Tinteiro p/ Epson Stylus Photo R200/R220/R300/R340/R320/R500/RX500/RX600/RX620/RX640 Azul Claro	15
PK-T0486	Tinteiro p/ Epson Stylus Photo R200/R220/R300/R340/R320/R500/RX500/RX600/RX620/RX640 Magenta Claro	15
PK-T0540	Tinteiro p/ Epson Stylus photo R800/R1800 Optimizador de Brilho	15
PK-T0541	Tinteiro p/ Epson Stylus Photo R800/R1800 Preto Photo	15
PK-T0542	Tinteiro p/ Epson Stylus Photo R800/R1800 Azul	15
PK-T0543	Tinteiro p/ Epson Stylus Photo R800/R1800 Magenta	15
PK-T0544	Tinteiro p/ Epson Stylus Photo R800/R1800 Amarelo	15
PK-T0547	Tinteiro p/ Epson Stylus Photo R800/R1800 Vermelho	15
PK-T0548	Tinteiro p/ EpsonStylus Photo R800/R1800 Preto Mate	15
PK-T0549	Tinteiro p/ Epson Stylus Photo R800/R1800 Azul Escuro	15
PK-T0551	Tinteiro p/ Epson Stylus Pro X420/425/520/R240 Preto	11
PK-T0552	Tinteiro p/ Epson Stylus Pro X420/425/520/R240 Azul	11
PK-T0553	Tinteiro p/ Epson Stylus Pro X420/425/520/R240 Magenta	11
PK-T0554	Tinteiro p/ Epson Stylus Pro X420/425/520/R240 Amarelo	11
PK-T0611	Tinteiro p/ Epson D68PE/D88+/DX3800/DX3850/DX4200/DX4250/DX4800/ DX4850 Preto	11

PK-T0612	Tinteiro p/ Epson D68PE/D88+/DX3800/DX3850/DX4200/DX4250/DX4800/ DX4850 Azul	11
PK-T0613	Tinteiro p/ Epson D68PE/D88+/DX3800/DX3850/DX4200/DX4250/DX4800/ DX4850 Magenta	11
PK-T0614	Tinteiro p/ Epson D68PE/D88+/DX3800/DX3850/DX4200/DX4250/DX4800/ DX4850 Amarelo	11
PK-T0711/T0891	Tinteiro p/ Epson Stylus S20/21/D78/D92/120/SX105/110/115/205/215/218/405/415/515W/600FW/610FW/DX40X0/44X0/50X0/60X0/7000F/74X0/84X0/940 0F/ Office B40W/BX300F/310FN/600FW/610FW/DX7400 Preto	15
PK-T0712/T0892	Tinteiro p/ Epson Stylus S20/21/D78/D92/120/SX105/110/115/205/215/218/405/415/515W/600FW/610FW/DX40X0/44X0/50X0/60X0/7000F/74X0/84X0/940 0F/ Office B40W/BX300F/310FN/600FW/610FW/DX7400 Azul	14
PK-T0713/T0893	Tinteiro p/ Epson Stylus S20/21/D78/D92/120/SX105/110/115/205/215/218/405/415/515W/600FW/610FW/DX40X0/44X0/50X0/60X0/7000F/74X0/84X0/940 0F/ Office B40W/BX300F/310FN/600FW/610FW/DX7400 Magenta	14
PK-T0714/T0894	Tinteiro p/ Epson Stylus S20/21/D78/D92/120/SX105/110/115/205/215/218/405/415/515W/600FW/610FW/DX40X0/44X0/50X0/60X0/7000F/74X0/84X0/940 0F/ Office B40W/BX300F/310FN/600FW/610FW/DX7400 Amarelo	14
PK-T066	Tinteiro p/ Epson Stylus C48 Preto	10
PK-T067	Tinteiro p/ Epson Stylus C48 Cores	23
PK-T0801/T0791	Tinteiro p/ Epson Stylus Photo P50/1400/R265/R285/360/RX560/RX585/685/PX700W/720WDPX800FW/810FW/820FWD Preto	11
PK-T0802/T0792	Tinteiro p/ Epson Stylus Photo P50/1400/R265/R285/360/RX560/RX585/685/PX700W/720WDPX800FW/810FW/820FWD Azul	11
PK-T0803/T0793	Tinteiro p/ Epson Stylus Photo P50/1400/R265/R285/360/RX560/RX585/685/PX700W/720WDPX800FW/810FW/820FWD Magenta	11
PK-T0804/T0794	Tinteiro p/ Epson Stylus Photo P50/1400/R265/R285/360/RX560/RX585/685/PX700W/720WDPX800FW/810FW/820FWD Amarelo	11
PK-T0805/T0795	Tinteiro p/ Epson Stylus Photo P50/1400/R265/R285/360/RX560/RX585/685/PX700W/720WDPX800FW/810FW/820FWD Light	11
PK-T0806/T0796	Tinteiro p/ Epson Stylus Photo P50/1400/R265/R285/360/RX560/RX585/685/PX700W/720WDPX800FW/810FW/820FWD Light Magenta	11
PK-T1281	Tinteiro p/ Epson Stylus S22/SX125/420W/425W/Office BX305F Preto	15
PK-T1282	Tinteiro p/ Epson Stylus S22/SX125/420W/425W/Office BX305F Azul	13
PK-T1283	Tinteiro p/ Epson Stylus S22/SX125/420W/425W/Office BX305F Magenta	13
PK-T1284	Tinteiro p/ Epson Stylus S22/SX125/420W/425W/Office BX305F Amarelo	13
PK-T1291	Tinteiro p/ Epson Stylus SX420W/425W/525WD/620FW/ Office BX305F/320FW/525WD/625FWD Preto	18
PK-T1292	Tinteiro p/ Epson Stylus SX420W/425W/525WD/620FW/ Office BX305F/320FW/525WD/625FWD Azul	15
PK-T1293	Tinteiro p/ Epson Stylus SX420W/425W/525WD/620FW/ Office BX305F/320FW/525WD/625FWD Magenta	15
PK-T1294	Tinteiro p/ Epson Stylus SX420W/425W/525WD/620FW/ Office BX305F/320FW/525WD/625FWD Amarelo	15
PK-T1301	Tinteiro p/ Epson Stylus SX525WD/620FW/ Office 525WD/625FWD Preto	32
PK-T1302	Tinteiro p/ Epson Stylus SX525WD/620FW/ Office 525WD/625FWD Azul	18
PK-T1303	Tinteiro p/ Epson Stylus SX525WD/620FW/ Office 525WD/625FWD Magenta	18
PK-T1304	Tinteiro p/ Epson Stylus SX525WD/620FW/ Office 525WD/625FWD Amarelo	18
PK-T050(093-187)	Tinteiro p/ Epson Stylus Color 400/500/600Photo/Photo 700/PhotoEX/Stylus Color 440/460/640/660/670/Fotografico750/Millennium/1200 Preto	16
PK-T051(108-189)	Tinteiro p/ Epson Stylus Color 740/760/860/1160//800/850/1520 Stylus Scan 2000/2500 Preto	24
PK-T052(089-191)	Tinteiro p/ Epson Stylus 440 / 460 / 640 / 660 400/600/800/760 Cor	33

PK-T053(110-193)	Tinteiro p/ Epson Stylus 720 / 750/700 / 710 / EX / EX2 Cor	45
PK-118	Tinteiro p/ Epson Stylus Color 3000/stylus pro 5000 Preto	110
PK-122	Tinteiro p/ Epson Stylus Color 3000/stylus pro 5000 Amarelo	110
PK-126	Tinteiro p/ Epson Stylus Color 3000/stylus Magenta	110
PK-130	Tinteiro p/ Epson Stylus Color 3000/stylus Cyan	110
PK-138	Tinteiro p/ Epson Stylus Color 300	37
PK-143	Tinteiro p/ Epson Stylus pro 5000 Magenta/ Magenta Claro	140
PK-147	Tinteiro p/ Epson Stylus pro 5000 Azul/ Azul Claro	140